



Activity Panel instructions and the Dash Manual. If you do not understand these instructions call Chicco at 1-877-424-4226. IMPORTANT: Make sure the Mattress Pad is installed and secured in the playard before placing your child inside.

## **INSTRUCTIONS:** Dash Activity Panel

IMPORTANT: Please also refer to the Owner's Manual that came with your product.



Unfold the Activity Panel and locate the the zipper on top of the Activity Panel. Attach the zipper to the matching zipper section on the playard. Pull the zipper across the back edge.



To remove the Dash Activity Panel, unzip the zipper and remove the panel.